

APPENDIX REM – REMOTE CONTROL PROTOCOL

Last Revised: 12 MAY 2014

Software Version: 0.06

This appendix describes the configuration required and the commands used to implement the remote control interface for the RC4000 antenna controller. It is provided as a supplement to the “baseline” RC4000 manual. Sections in the baseline RC4000 manual are referred to when data specific to the remote control option are described.

NOTE: RC4000 software is built on a per-mount basis. Some commands may not be available on all devices.

Revision History

| | | |
|-------------|--|-----|
| 01 OCT 2013 | Document added to version control system. | ECG |
| 20 OCT 2013 | Added Write Config Data command and notes to appropriate sections. | ECG |
| 04 NOV 2013 | Added local jog alarm. Added feed index to status reply. | ECG |
| 03 DEC 2013 | Update special axis limits to match change to ACU scheme. | ECG |
| 22 JAN 2014 | Added indication that some commands return the status reply. | ECG |
| 12 MAY 2014 | Updated move state descriptions in status reply. | ECG |

1.0 THEORY OF OPERATION

Overview

The RC4000 supports a variety of remote monitor and control commands. The controller functions as a slave device within a network. The network is expected to consist of one master and multiple slaves communicating over a single interface (or "bus"). Each slave is internally configured with a unique address.

Message Protocol

Message format and protocol over the bus is a derivative of IBM's binary synchronous communications protocol (BISYNC). The master station sends a command over the bus to all slave devices. The device whose address is specified in the command message carries out the requested commands, and then replies with a response message containing the result. A device does not respond if the command does not contain its address. This prevents bus contention caused by more than one remote device communicating over the bus at the same time. NOTE: Even if the antenna controller is the only device on the network, it still must be addressed.

Data Format

All data should be in 7-bit ASCII format. The control character subset 00-1F (hex) is reserved for message control. The printable ASCII characters 20-7F (hex) are used for address, command and data characters.

Message Format

Command messages begin with the STX (Start-of-text) byte followed by a remote address, a command byte and multiple data bytes. The ETX (End-of-text) byte is sent following the last data byte, and the message is terminated by a Checksum character. Response messages are identical to command messages in format with the exception of the ACK (Acknowledge) or NAK (Not Acknowledge) byte at the start of the message instead of STX. Figure 1 illustrates the format of the command and response messages. A command or reply message may have a variable length.




Figure 1 – Message Format

Message Delimiters

A command message begins with STX (02 hex). A reply begins with ACK (06 hex) or NAK (15 hex) depending on the result of the command execution. All messages end with the ETX (03 hex), the ASCII End-of-text control character, followed by the Checksum byte.

Address Byte

The device address (ADDR) must be a valid ASCII printable character between 49 (31 hex) and 111 (6F hex); thus, 63 addresses are possible.

Command Byte

The command byte (CMD) immediately follows the device address and specifies one of several possible commands for a particular device.

Checksum Byte

The last character of any message is the Checksum byte (CHK). This character is simply the bit-by-bit exclusive OR of all characters in the message starting with the STX character through the ETX character. This forms a Longitudinal Redundancy parity check over the entire message.

Message Timing

The NAK or ACK reply does not signify that a function has actually taken place, but only that the message was received and understood. The user should query the controller later to see if the command was actually carried out, or is still in progress.

Command Restrictions

All RC4000 devices will respond to a command "0" (30 hex) with 6 data bytes of ASCII characters in the following form:

| | | | | | | | | | | |
|-----|------|-----|---|---|----------------|---|----------------|----------------|-----|--------|
| ACK | ADDR | 30h | 4 | K | D ₁ | . | D ₂ | D ₃ | ETX | CHKSUM |
|-----|------|-----|---|---|----------------|---|----------------|----------------|-----|--------|

where D₁.D₂D₃ are ASCII characters representing a software version number (e.g. 1.12).

State Diagram

The state diagram below illustrates processing of communication messages by the slave device. Each state is represented graphically as a circle with a single-digit number. All transitions between states are represented graphically by arrows between them. Each transition is qualified by conditions that must be true in order for the transition to occur.




Figure 2 – SA Bus Protocol State Diagram

State Descriptions

- State 1 – Idle State
 - The device is ready to receive a new message. A device always powers on in State 1.
 - The device will enter State 2 only if the STX byte is received.
- State 2 – Addressed State
 - The device is waiting to receive the address byte.
 - The device will enter:
 - State 3 if the received address byte is correct.
 - State 1 if the received address is not correct.
 - The device will stay in State 2 if the STX byte is received.
- State 3 – Data State
 - The device is engaged in receiving the command data from the master.
 - The device will enter:
 - State 4 if the ETX byte is received signifying the end of data in the message.
 - State 1 if the STX byte, an invalid byte, or the incorrect number of data bytes is received.
- State 4 – Data Error State
 - The device is waiting to receive a Checksum byte.
 - A slave will enter:
 - State 5 if the received Checksum byte equals the LRC value computed during message reception.
 - State 1 if the received Checksum byte does not equal the LRC value computed during message reception.
- State 5 – Command Execute State
 - The device begins execution of the received command.
 - The device begins sending the appropriate response message to the master.
 - The device will enter State 1 only when the entire response has been transmitted.

2.0 CONFIGURATION

Electrical Interface

The RC4000 can interface with a variety of physical interfaces including Ethernet, RS-232, or RS-422. Refer to section 2.1.2.3.9 of the baseline RC4000 manual and supplemental appendix IP for more information on interfacing with an Ethernet network. Refer to section 2.1.2.2.4 of the baseline RC4000 manual for more information on interfacing with a serial network.

Communications Parameters

When the RC4000 is expected to be controlled via a RS-232 or RS-422 network, the controller's baud rate and address must be set. These values can be specified via the REMOTE CONTROL configuration screen.

| | |
|---------------------------------------|---------------|
| ENABLED: 1 | CONFIG-REMOTE |
| ADDRESS: 50 | MODE: 1 |
| BAUD_RATE: 6 | JOG: 20 |
| REMOTE CONTROL <0>DISABLED <1>ENABLED | |

ENABLED: **REMOTE CONTROL <0>DISABLED <1>ENABLED**

This item allows the user to disable the ability to remotely control the RC4000. This may prove useful if the user wants to only operate from the front panel.

ADDRESS: **BUS ADDRESS <49-111>**

This item allows the user to specify an unique bus address for the RC4000. The default address is 50.

BAUD RATE: **BAUD <1-3 2-6 3-12 4-24 5-48 6-96>(x100)**

This item allows the user to choose one of six possible baud rates from 300 to 9600. The default baudrate is 9600.

MODE: **REMOTE MODE <0-RS232 1-RS422>**

This item allows the user to select RS232 or RS422/RS485 operation. The RC4000 is shipped from the factory configured for RS-232 operation

JOG: **REMOTE JOG HOLD <1-40>**

This configuration item exists to allow the RC4000 to adjust to the required key repeat rate from the computer sending the remote front panel commands. This value will have to be adjusted to match the latency of different computers implementing a "remote front panel" scheme.

The REMOTE JOG HOLD value is used to jog movements when the RC4000 is operating in MANUAL mode and being commanded via a remote front panel. The entered number multiplied by 1/40 of a second represents how long a remote front panel jog command will last. For example, a value of 20 corresponds to a hold period of 0.5 seconds.

If the value is too low, manual movements will be jerky as the operator holds down a jog key from the remote front panel. In this case the RC4000 sees a jog key from the remote front panel but the hold timer expires before another jog key command is received.

3.0 DETAILED OPERATION

RC4000 Online/Offline Reply

The RC4000 software must include a remote control option to process commands. If remote control is not available, and a valid message is received (correct format, address, Checksum, etc.), the offline reply is sent to the host. This reply has the following format:

| | | |
|--------|----------|--------------------------------------|
| byte 0 | ACK | |
| byte 1 | A | RC4000 address |
| byte 2 | CC | command code of the received message |
| byte 3 | 'F' | ASCII 'F', for offline. |
| byte 4 | ETX | |
| byte 5 | Checksum | |

RC4000 Unrecognized Commands – NAK Reply

If a valid message is received but the command code is unrecognized or unavailable, or if an error occurred while processing the command data, a NAK reply is sent to the host. Additional failure information may be available for specific commands. The NAK reply has the following format:

| | | |
|--------|----------|--|
| byte 0 | NAK | |
| byte 1 | A | RC4000 address |
| byte 2 | CC | command code of the unrecognized message |
| byte 3 | ETX | |
| byte 4 | Checksum | |

RC4000 Command Acknowledged – ACK Reply

In many cases, if a command is received but no response is required, a standard ACK reply is sent to the host. The standard ACK reply has the following format:

| | | |
|--------|----------|--|
| byte 0 | ACK | |
| byte 1 | A | RC4000 address |
| byte 2 | CC | command code of the acknowledged message |
| byte 3 | ETX | |
| byte 4 | Checksum | |

Command Set

The following table lists the available RC4000 remote commands.

Each command is detailed in the paragraphs listed below.

Table 1 – Command Set List

| CODE (hex) | COMMAND | PARAGRAPH |
|------------|--|-----------|
| 30 | Device Type | 3.1 |
| 31 | Device Status | 3.2 |
| 32 | Auto Move | 3.3 |
| 33 | Azimuth / Elevation / Polarization Jog | 3.4 |
| 34 | Polarization | 3.5 |
| 35 | Query Name | 3.6 |
| 36 | Miscellaneous | 3.7 |
| 37 | Reflect Display | 3.8 |
| 38 | Reserved | |
| 39 | Write Satellite Data ¹ | 3.9 |
| 3A | Read Satellite Data | 3.10 |
| 3B | Write Two Line Element Data ¹ | 3.11 |
| 3C | Read Two Line Element Data | 3.12 |
| 3D | Write Beacon Data ¹ | 3.13 |
| 3E | Read Beacon Data | 3.14 |
| 3F | Read Pulse Count | 3.15 |
| 40 | Extended Device Status | 3.16 |
| 41 | Remote Locate | 3.17 |
| 42 | Remote Store | 3.18 |
| 43 | Write Signpost Data ¹ | 3.19 |
| 44 | Read Signpost Data | 3.20 |
| 45 | Read Navigation Data | 3.21 |
| 46 | Write Navigation Data | 3.22 |
| 47 | Jog with Minimal Reply | 3.23 |
| 48 | Remote Key Press | 3.24 |
| 49 | Write Config Data ¹ | 3.25 |
| 4A | Reserved | |
| 4B | Custom Device Status ² | 3.26 |
| | | |
| | 1 – requires flash save | |
| | 2 – experimental | |

3.1 Device Type Query Command

The SA Bus specification requires that command character 30h must trigger the return of the six character device type string. The message format for this query will be:

| | | |
|--------|----------|--------------|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 30h | command code |
| byte 3 | ETX | |
| byte 4 | Checksum | |

The reply to this query will consist of 11 bytes:

| | | |
|-----------|----------|--------------------------------|
| byte 0 | ACK | |
| byte 1 | A | address |
| byte 2 | 30h | command code |
| bytes 3,4 | "46" | controller type |
| bytes 5-8 | "A.BC" | version number – example: 1.22 |
| byte 9 | ETX | |
| byte 10 | Checksum | |

3.2 Device Status Command

The SA Bus specification requires that command character 31h cause a device to return status information. The reply to this command includes azimuth, elevation and polarization position, current satellite name, as well as limit, alarm and drive status information. The status poll command message consists of 5 bytes and the format is:

| | | |
|--------|----------|--------------|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 31h | command code |
| byte 3 | ETX | |
| byte 4 | Checksum | |

The response to this command will consist of 52 bytes, which will be a combination of ASCII and binary data fields. The binary data will be placed in the lower nibble of a byte whose higher nibble will be initialized to a value which will make the result an ASCII character. The idea with this response is to be able to reproduce the information presented on the LCD to the user when manual mode is active. The format of the response is:

| | | |
|------------|----------|---|
| byte 0 | ACK | |
| byte 1 | A | address |
| byte 2 | 31h | command code |
| bytes 3-12 | Sat Name | This field will contain the satellite name in upper case letters. If the name does not occupy the entire field the name will be left justified and the string will be padded with blanks. If a satellite name is not currently displayed, this field will contain blanks. |
| byte 13 | Reserved | |

Device Status Command (continued)

byte 14-19 Azimuth Position
 byte 20-25 Elevation Position
 byte 26-31 Polarization Position

These fields will contain the formatted azimuth, elevation, and polarization position from -180.0 to 180.0.
 If an error is detected, this field will contain '*****'.

byte 32 Azimuth Limits – binary data
 byte 33 Elevation Limits – binary data
 byte 34 Polarization Limits – binary data

```

7 6 5 4   3 2 1 0
0 1 0 0 $ 0 A B C
  
```

These fields contain azimuth, elevation, and polarization limit information. Bits 'A', 'B', and 'C' indicate the limit status. A '0' in a bit position implies that the antenna is not at the limit, a '1' in the bit position implies that the antenna is at the limit. The bit position to limit is defined as:

A – Maximum Limit (CW, UP, CW)
 B – Minimum Limit (CCW, DOWN, CCW)
 C – Stow Limit

byte 35 Polarization equipment and display status code – binary data

```

7 6 5 4   3 2 1 0
0 1 X X $ Y Z Z Z
  
```

Where 'XX' is defined as:

00 – rotating feed is not present in the system
 01 – single port rotating feed is present in the system
 10 – dual port rotating feed is present in the system.

Where 'Y' is defined as:

0 – polarization movements are not allowed
 1 – polarization movements are allowed

Where 'ZZZ' is defined as:

000 – 'H' polarization code is displayed
 001 – 'h' polarization code is displayed
 010 – 'V' polarization code is displayed
 011 – 'v' polarization code is displayed
 100 – no polarization code is displayed

Device Status Command (continued)

byte 36 Azimuth Movement/Alarm Status – binary data
 byte 37 Elevation Movement/Alarm Status – binary data
 byte 38 Polarization Movement/Alarm Status – binary data

```

7 6 5 4   3 2 1 0
0 1 0 S $ X X X X

```

Where 'S' is defined as:

0 – Axis Is Configured For Slow Speed Movement
 1 – Axis Is Configured For Fast Speed Movement

Where 'XXXX' is defined as:

0000 – No Alarms or Movement
 0010 – Negative Jog Movement (CCW, DOWN, CCW)
 0011 – Positive Jog Movement (CW, UP, CW)
 0100 – Negative Automatic Movement (CCW, DOWN, CCW)
 0101 – Positive Automatic Movement (CW, UP, CW)
 0111 – Auto Move Is In Progress
 1010 – Runaway Alarm Active
 1011 – Jammed Alarm Active
 1100 – Drive Alarm Active

Higher value status codes have priority over lower value ones. If as part of an auto move command the antenna is moving clockwise the status will be reported as 'auto move in progress' rather than 'clockwise movement in progress'.

Device Status Command (continued)

byte 39 Alarm Code – binary data

```

7 6 5 4   3 2 1 0
0 1 A A $ A A A A

```

Where A5–A0 specify the alarm code (0-63). Alarm messages flash on the bottom row of the display. NOTE: Some software versions have mount-specific alarm codes.

The following alarm codes have been defined for software v0.05 and below:

- 0 – No Alarm Active
- 1 – Low Battery
- 2 – Azimuth Jammed
- 3 – Azimuth Runaway
- 4 – Elevation Jammed
- 5 – Elevation Runaway
- 18 – Time/Date Error
- 22 – Polarization Jammed
- 24 – Limits Inactive Warning
- 27 – Emergency Stop
- 28 – Flash Version Mismatch
- 29 – Flash Data Corrupt
- 30 – NVRAM Version Mismatch
- 31 – NVRAM Data Corrupt
- 32 – Antenna Halt

The following alarm codes have been defined for software v0.06 and above:

- 0 – No Alarm Active
- 1 – Flash Version Mismatch
- 2 – Flash Data Corrupt
- 3 – NVRAM Version Mismatch
- 4 – NVRAM Data Corrupt
- 5 – Low Battery
- 6 – Time/Date Error
- 7 – Azimuth Jammed
- 8 – Azimuth Runaway
- 9 – Elevation Jammed
- 10 – Elevation Runaway
- 11 – Polarization Jammed
- 12 – Polarization Runaway
- 13 – Limits Inactive Warning
- 14 – Drive Error
- 15 – Emergency Stow
- 16 – Hand Crank Interlock
- 17 – Movement Interlock
- 18 – Local Jog Connected

Device Status Command (continued)

byte 40 Track Mode track submode status and frequency band – binary data

```

7 6 5 4    3 2 1 0
0 B B B $ S S S S

```

Where 'BBB' is defined as:

```

000 – Reserved
001 – X Band
010 – Ka Band
011 – S Band
100 – C Band
101 – Ku Band
110 – Reserved
111 – L Band

```

Where 'SSSS' is defined as:

```

0000 – Track Mode Not Active
0001 – Track Setup Sub-Mode Active
0010 – Track Auto Mode Entry
0011 – Step Track Sub-Mode Active
0100 – Track Auto Search Sub-Mode Active
0101 – Program Track Sub-Mode Active
0110 – Track Manual Search Sub-Mode Active
1000 – Track Jammed Error
1001 – Track Limit Error
1010 – Track Drive Error
1011 – Track Peak Limit Error
1100 – Track Geo Position Error
1101 – Track System Error
1110 – Track Checksum Error

```

bytes 41-44 AGC Level Current AGC channel voltage from 0 and 4095, right justified and padded with blanks (on the left).

byte 45 AGC Channel Current AGC channel and lock status – binary data

```

7 6 5 4    3 2 1 0
0 1 0 L $ 0 C C C

```

Where 'CCC' is defined as:

```

000 – RF
001 – SS1
010 – SS2
011 – DVB
1xx – reserved

```

Where 'L' is defined as:

```

1 – lock indicated
0 – no lock indicated

```

Device Status Command (continued)

byte 46 HPA Relay/Feed ID Status – binary data

```

7 6 5 4    3 2 1 0
0 1 0 B $ B B A A

```

Where 'AA' is defined as:

```

00 – HPA Relay Disabled by ACU Software
01 – HPA Relay Disabled by External TX Mute
10 – HPA Relay Enabled
11 – Reserved

```

The bit field 'BBB' indicates the current feed id index which will be a value between 0 and 7. The value will be 0 if feed id bits are not supported.

byte 47 Special Axis Limits/Movement Status – binary data

```

7 6 5 4    3 2 1 0
0 1 0 S $ A B C D

```

Where 'S' is defined as:

```

0 – Axis Not Moving
1 – Axis Auto Move Is In Progress

```

Bits A - D indicate the status of Limit A - D respectively. A '0' in a bit position implies that the axis is not at the limit, and a '1' implies that the axis is at the limit. The meaning of each limit is described under Form 3 of the Auto Move command.

bytes 48–49 Reserved

byte 50 ETX

byte 51 Checksum

3.3 Auto Move Command

This command causes the controller to automatically position the antenna in azimuth, elevation, and polarization. The command contains 16 bytes formatted as follows:

| | | |
|-----------|--------------|---|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 32h | command code |
| byte 3 | Polarization | ' ' (blank), 'C', 'A', 'E', 'P', '+', 'S' |
| byte 4-13 | Position | target satellite name or position data |
| byte 14 | ETX | |
| byte 15 | Checksum | |

The Auto Move command has several forms:

Form 1: Automates the RC4000 RECALL mode. If the position field contains the name of a satellite saved via the controller's STORE mode the controller will position the antenna at the azimuth and elevation positions associated with that satellite. The satellite name should be in capital letters, left justified and padded on the right with blanks. NOTE: The satellite name specified in the command must exactly match a satellite name.

With this form of the command, the polarization field may contain either 'H', 'V', or ' ' (blank). If 'H' or 'V' is specified, in addition to positioning the antenna in azimuth and elevation, the polarization control device will be commanded to go to the position associated with either the horizontal or vertical position specified for the satellite. If the field contains a blank the polarization is not changed. For example, this command with 'H' in the polarization field and 'SBS 6 ' in the position field will specify an auto move to SBS 6 and the polarization will be adjusted to horizontal for the SBS 6 satellite.

Form 2A: If the position field contains a valid pair of azimuth and elevation sensor positions (scaled by 10), the antenna will move to the position specified. The first 5 characters of the position field specify the azimuth position (azimuth sub-field) and the last five characters specify the elevation position (elevation sub-field). Within each of the sub-fields the position must be right justified and left padded with zeroes. For example, a position field value of '-152500456' specifies an azimuth position of -152.5 degrees and an elevation position of 45.6 degrees. For this form of the auto move command, only the ' ' (blank) character is accepted in the polarization field. If the simultaneous azimuth/elevation drive option is not enabled, the controller will move elevation first and azimuth second.

Form 2B: If the antenna system is equipped with "count" sensors (pulse or resolvers), the antenna will move to the count values specified. For example, a position field value of '1105012152' specifies an azimuth pulse position of 11050 and an elevation pulse position of 12152. The polarization field should contain a 'C'. Note that if no "count" sensor is available, a NAK reply will be sent to the host.

Form 2C: For systems that are capable of generating azimuth, elevation, or polarization position feedback to the one hundredth of a degree resolution, form 2C provides the capability to command either an azimuth or an elevation movement to a target specified within one hundredth of a degree. To command an azimuth, elevation, or polarization move, insert 'A', 'E', or 'P' into byte 3. Bytes 4 to 9 contain the target azimuth, elevation, or polarization position. As with form 2A, the position must be right justified and left padded with zeroes. Bytes 10 to 13 should be filled with blanks. For example, if byte 3 is 'A' and bytes 4 – 9 contain '-12345', an azimuth auto move to the target of -123.45 will be initiated. Note that if one hundredth of a degree resolution is not available, the hundredth place digit will be ignored.

Auto Move Command (continued)

Form 2D: If the position field contains a valid pair of azimuth and polarization sensor positions (scaled by 10), the antenna will move to the position specified simultaneously. The first 5 characters of the position field specify the azimuth position (azimuth sub-field) and the last five characters specify the polarization position (polarization sub-field). Within each of the sub-fields the position must be right justified and left padded with zeroes. For example, a position field value of '-152500456' specifies an azimuth position of -152.5 degrees and an polarization position of 45.6 degrees. For this form of the auto move command, only the '+' character is accepted in the polarization field. If the simultaneous azimuth/polarization drive option is not enabled, the controller will move polarization first and azimuth second.

Form 3: This form is only available on mount types where the antenna system is equipped with a special "fourth axis" of motion. The polarization field should contain an 'S'. Byte 4 will contain the special axis code. Byte 5 will contain the target position. The possible combinations for bytes 4 and 5 are shown below. Bytes 6 to 13 should be filled with blanks.

The remote status command can be used to get the current special axis state position if limit switch feedback is available. If a limit is active, a '1' will be present in the bit position indicated below (A, B, C, or D). If a limit is not active, a '0' will be present instead. In the case of a mutually exclusive limit, either a '0' or a '1' will be present.

| SPECIAL AXIS | AXIS CODE | DIRECTION CODE | LIMIT CONDITION |
|-------------------|-----------|---|-------------------------|
| Waveguide 1 | W | H – horizontal (pos 1) V – vertical (pos 2) | B = 1 C = 1 |
| RF Switch | R | 1 – path 1 2 – path 2 | A = 0 A = 1 |
| Polarization Mode | P | L – linear mode C – circular mode | B = 1 C = 1 |
| Fairing Control | F | D – move to deploy S – move to stow M – move to maintenance | B = 1 C = 1 D = 1 |

The ACK reply to this command will be in the same format as the Device Status Command. If the target positions for a move are not specified properly a NAK reply will be sent to the host. If the command specifies polarization movement but the Polarization Type is set to CIRCULAR, ACK will be received, but no movement will occur.

3.4 Azimuth/Elevation/Polarization Jog Command

This command jogs the antenna in azimuth, elevation, or polarization. The command contains 11 bytes. Here is the format of the command:

| | | |
|-----------|-----------|--|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 33h | command code |
| byte 3 | Direction | This field can specify one of the following: E – Azimuth Counter Clockwise W – Azimuth Clockwise D – Elevation Down U – Elevation Up O – Polarization Counter Clockwise L – Polarization Clockwise X – Stop All Movement |
| byte 4 | Speed | Specifies the jog speed, either 'F' (Fast) or 'S' (Slow). This field must contain a valid value even if the direction field specifies 'X' (Stop). |
| bytes 5-8 | Duration | Length to continue the jog milliseconds from '0000' to '9999'. This field must contain a valid value even if the direction field specifies 'X' (Stop). NOTE: The resolution of the timer used to make the move is approximately 10 milliseconds. All durations converted to the closest multiple. |
| byte 9 | ETX | |
| byte 10 | Checksum | |

The ACK reply to this command will be in the same format as the Device Status Command.

NOTE: The controller can only support a remote jog about a single axis. For example, if a remote jog is in progress about the azimuth axis and a remote elevation jog command is received, the azimuth jog will terminate regardless of the duration specified for the remote azimuth jog.

3.5 Polarization Command

The following command specifies a move to a calculated polarization position. The command contains 6 bytes. The format of the command is as follows:

| | | |
|--------|----------|---|
| byte 0 | STX | |
| byte 1 | A | RC4000 address |
| byte 2 | 34h | the command code |
| byte 3 | 'X' | this field will specify either 'H', 'V', or 'X' where: H/V -- moves the polarization to the horizontal/vertical polarization position associated with the last auto move target satellite X -- moves the polarization 90 degrees from the current polarization position |
| byte 4 | ETX | |
| byte 5 | checksum | |

If the Polarization Type is set to DUAL (2 Port Feed) either the 'H' or 'V' argument will result in a move to the single polarization position associated with the satellite. The ACK reply to any form of this command will be in the same format as the Device Status Command.

NOTE: This command is only available while MANUAL or TRACK mode is active.

3.6 Query Name Command

This command can be used to retrieve the name of a satellite saved via the controller's STORE mode. The command contains the index of the desired entry in the satellite list. A maximum of 50 satellites can be stored in memory.

This query command contains 7 bytes and the format is:

| | | |
|-----------|----------|---|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 35h | command code |
| bytes 3-4 | 'XX' | Where XX is the index of the satellite name being requested. Normally this would be '01' the first time through and then incremented until the 'YY' (YY being the last entry in the list) satellite name is read. The maximum possible range for XX and YY is 1 through 50. |
| byte 5 | ETX | |
| byte 6 | Checksum | the Checksum |

The response to this command contains 19 bytes and the format is:

| | | |
|------------|------------|---|
| byte 0 | ACK or NAK | |
| byte 1 | A | address |
| byte 2 | 35h | the query name command code |
| bytes 3-4 | 'XX' | Where XX is the index of the satellite name being requested. |
| bytes 5-6 | 'YY' | Where YY is the total number of satellite names contained in the list. Repeat this command YY times to download the names of all stored satellites. |
| bytes 7-16 | Sat Name | This field will contain the satellite name. The name will be in capital letters and normally be left justified. The only time the satellite name will not be left justified is if the user selected the USER entry from STORE mode and manually entered blank characters before the satellite name. |
| byte 17 | ETX | |
| byte 18 | Checksum | |

NOTE: If entry 'XX' does not exist in the list (or the list has no entries) the NAK reply will be sent back to the host.

3.7 Miscellaneous Command

This command performs miscellaneous functions. Here is the format of the command.

| | | |
|--------|----------|---------------------------|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 36h | command code |
| byte 3 | 'X' | the sub-command code |
| byte 4 | 'Y' | the sub-command parameter |
| byte 5 | ETX | |
| byte 6 | Checksum | |

The sub-command code 'X' can have the following values:

| | |
|-----------|---|
| 'X' = 'R' | This sub-command can be used to reset the azimuth, elevation, or polarization drive alarms. The sub-command parameter 'Y' must be 'A', 'E', or 'P' (for azimuth, elevation, or polarization respectively). |
| 'X' = 'T' | This sub-command can be used to reset track mode errors with parameter 'Y' = R. When the TRACK sub-mode ERROR is active this command will cause the ERROR sub-mode to terminate. The controller will react as if TRACK mode was activated via RECALL mode. The reply will be a NAK if TRACK mode is not active. NOTE: If a system error is active (an error message flashing on the bottom row of the display) the condition which generated the system error must be rectified or the controller will immediately return to the TRACK mode ERROR sub-mode. This sub-command can also be used to switch bands when a dual band satellite is being tracked. A sub-command parameter of 'C' will specify C band and 'K' will specify K band. The reply will be a NAK if TRACK mode is not active or the satellite being tracked was not specified as a dual band satellite (when the track was initiated via SETUP mode). |
| 'X' = 'S' | This sub-command is used to initiate an automatic antenna STOW via the RC4000. |
| 'X' = 'D' | This sub-command is used to initiate an automatic antenna DEPLOY via the RC4000. |

The ACK reply to this command will be in the same format as the Device Status Command.

3.8 Reflect Display Command

This command requests the RC4000 to send the 160 (4 rows x 40 columns) characters currently displayed on the LCD. The command format is:

| | | |
|--------|----------|--------------|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 37h | command code |
| byte 3 | ETX | |
| byte 4 | Checksum | |

The response to this command will be to send the 160 displayed characters in ASCII format plus cursor status. The response format is:

| | | |
|--------------|---------------|--|
| byte 0 | ACK | |
| byte 1 | A | address |
| byte 2 | 37h | command code |
| byte 3-42 | Row 1 | 40 characters displayed on row 1 of the LCD |
| byte 43-82 | Row 2 | 40 characters displayed on row 2 of the LCD |
| byte 83-122 | Row 3 | 40 characters displayed on row 3 of the LCD |
| byte 123-162 | Row 4 | 40 characters displayed on row 4 of the LCD |
| byte 163 | Cursor Row | cursor row position (1-4) |
| byte 164-165 | Cursor Column | cursor column (01-40) |
| byte 166 | Cursor Status | 0 = cursor not blinking, 1 = cursor blinking |
| byte 167 | ETX | |
| byte 168 | Checksum | |

NOTE: The reply to this command is very lengthy and should be limited to a frequency less than 2 Hz.

3.9 Write Satellite Data Command

This command downloads satellite data into the RC4000 list of preset satellites. Storage for 20 satellites is available.

| | | |
|-------------|-------------|---|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 39h | command code |
| byte 3-4 | Index | Preset satellite table index (01–20) |
| bytes 5-14 | Sat Name | 10 character satellite name |
| bytes 15-20 | Longitude | Nominal satellite longitude -179.9 to 179.9 (West longitude negative) Left Justify and pad with blanks |
| bytes 21-22 | Inclination | Satellite inclination 0 to 19 Left Justify and pad with blanks |
| byte 23 | Band | RF Band (0-C, 1-Ku, 2-C/Ku, 3-L, 4-X, 5-Ka, 6-S) |
| byte 24 | Ephem | Ephemeris Data Present (0-none, 1-TLE, 2-IESS-412) |
| bytes 25-29 | Pol Offset | Polarization Offset -90.0 to 90.0 negative = counterclockwise Left Justify and pad with blanks |
| byte 30 | | ETX |
| byte 31 | | Checksum |

The reply to this command will be the standard ACK or NAK reply.

Data written with this command must be saved to persist between power cycles. The Write Config Data Command should be executed after all changes have been made. Refer to section 3.25 of this document for more information.

3.10 Read Satellite Data Command

This command uploads a stored set of satellite data to the RC4000.

| | | |
|----------|-------|--------------------------------------|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 3Ah | command code |
| byte 3-4 | Index | Preset satellite table index (01–20) |
| byte 5 | | ETX |
| byte 6 | | Checksum |

The reply to this command is as follows:

| | | |
|-------------|-------------|--|
| byte 0 | | ACK or NAK |
| byte 1 | | address |
| byte 2 | | 3Ah |
| byte 3-4 | Index | Preset satellite table index (01–20) |
| bytes 5-14 | Sat Name | 10 character satellite name to be associated with index |
| bytes 15-20 | Longitude | Nominal satellite longitude -179.9 to 179.9 (West longitude negative) Left Justify and pad with blanks |
| bytes 21-22 | Inclination | Satellite inclination 0 to 19 Left Justify and pad with blanks |
| byte 23 | Band | RF Band (0-C, 1-Ku, 2-C/Ku, 3-L, 4-X, 5-Ka, 6-S) |
| byte 24 | Ephem | Ephemeris Data Present (0-none, 1-TLE, 2-IESS-412) |
| bytes 25-29 | Pol Offset | Polarization Offset -90.0 to 90.0 negative = counterclockwise Left Justify and pad with blanks |
| byte 30 | ETX | |
| byte 31 | Checksum | |

3.11 Write Two Line Element Data Command

This command writes NORAD Two Line Element (TLE) ephemeris data into the RC4000. The index must be the same as the associated sat preset data index.

| | | |
|--------------|------------|--|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 3Bh | command code |
| bytes 3-4 | Index | Preset satellite table index (01–20) |
| bytes 5-73 | TLE Line 1 | 69 characters (including checksum) of TLE Line 1 |
| bytes 74-142 | TLE Line 2 | 69 characters (including checksum) of TLE Line 2 |
| byte 143 | ETX | |
| byte 144 | Checksum | |

The reply to this command will be the standard ACK or NAK reply.

Data written with this command must be saved to persist between power cycles. The Write Config Data Command should be executed after all changes have been made. Refer to section 3.25 of this document for more information.

3.12 Read Two Line Element Data Command

This command reads a stored set of Two Line Element (TLE) data. The index must be the same as the associated sat preset data index.

| | | |
|-----------|----------|--------------------------------------|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 3Ch | command code |
| bytes 3-4 | Index | Preset satellite table index (01–20) |
| byte 5 | ETX | |
| byte 6 | Checksum | |

The reply to this command is as follows:

| | | |
|--------------|------------|--|
| byte 0 | ACK or NAK | |
| byte 1 | A | |
| byte 2 | 3Ch | command code |
| bytes 3-4 | Index | Preset satellite table index (01–20) |
| bytes 5-73 | TLE Line 1 | 69 characters (including checksum) of TLE Line 1 |
| bytes 74-142 | TLE Line 2 | 69 characters (including checksum) of TLE Line 2 |
| byte 143 | ETX | |
| byte 144 | Checksum | |

3.13 Write Beacon Data Command

This command writes beacon frequency and tuning data into the RC4000. The index must be the same as the associated sat preset data index.

| | | |
|-------------|----------|---|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 3Dh | command code |
| bytes 3-4 | Index | Preset satellite table index (01–20) |
| bytes 5-12 | H-Freq | Horizontal beacon frequency (MHz) in the format (dddd.dd) |
| bytes 13-20 | V-Freq | Vertical beacon frequency (MHz) in the format (dddd.dd) |
| byte 21 | Demod | Beacon modulation: '0' = CW, '1' = BPSK |
| bytes 22-31 | Reserved | fill with zeroes or blanks |
| byte 32 | ETX | |
| byte 33 | Checksum | |

The reply to this command will be the standard ACK or NAK reply.

Data written with this command must be saved to persist between power cycles. The Write Config Data Command should be executed after all changes have been made. Refer to section 3.25 of this document for more information.

3.14 Read Beacon Data Command

This command reads beacon frequency and tuning data. The index must be the same as the associated sat preset data index.

| | | |
|-----------|----------|--------------------------------------|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 3Eh | command code |
| bytes 3-4 | Index | Preset satellite table index (01–20) |
| byte 5 | ETX | |
| byte 6 | Checksum | |

The reply to this command is as follows:

| | | |
|-------------|------------|--|
| byte 0 | ACK or NAK | |
| byte 1 | A | |
| byte 2 | 3Eh | command code |
| bytes 3-4 | Index | Preset satellite table index (01–20) |
| bytes 5-12 | H-Freq | Horizontal beacon frequency (MHz) in the format (dddd.d) |
| bytes 13-20 | V-Freq | Vertical beacon frequency (MHz) in the format (dddd.d) |
| byte 21 | Demod | Beacon modulation: '0' = CW, '1' = BPSK |
| bytes 22-31 | Reserved | |
| byte 32 | | ETX |
| byte 33 | | Checksum |

3.15 Read Pulse Count Command

The Read Pulse Count command returns the current value of azimuth and elevation pulse or resolver counts. The message format for this command will be:

| | | |
|--------|----------|--------------|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 3Fh | command code |
| byte 3 | ETX | |
| byte 4 | Checksum | |

The reply to this query will consist of 15 bytes:

| | | |
|------------|----------|---|
| byte 0 | ACK | |
| byte 1 | A | address |
| byte 2 | 3Fh | command code |
| bytes 3-7 | Az Count | Azimuth pulse or resolver count value |
| bytes 8-12 | EI Count | Elevation pulse or resolver count value |
| byte 13 | ETX | |
| byte 14 | Checksum | |

3.16 Extended Device Status Command

This command is an extension of the Device Status Command. The reply to this command provides all the information of the Device Status Command along with additional information including the current mode and state of the RC4000.

The Extended Device Status Poll command consists of 5 bytes with the following format:

| | | |
|--------|----------|--------------|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 40h | command code |
| byte 3 | ETX | |
| byte 4 | checksum | |

The response to this command will consist of 52 bytes, which will be a combination of ASCII and binary data fields. The binary data will be placed in the lower nibble of a byte whose higher nibble will be initialized to a value that will make the result an ASCII character. The format of the response is:

| | | |
|------------|--------------|---|
| byte 0 | ACK | |
| byte 1 | A | address |
| byte 2 | 40h | command code |
| bytes 3-49 | Status Reply | These bytes are identical to bytes 3-49 of the Device Status reply. See paragraph 3.2 for detail on the fields contained in this section. |
| byte 50 | Current Mode | This byte contains a value reflecting the current mode with control of the RC4000. See section A.3 of this document for more information about the available values for this field. |

Extended Device Status Command (continued)

| | | |
|-------------|-----------------------------|---|
| byte 51 | Current State | This byte contains a value reflecting the current state within the current mode. See section A.3 of this document for more information about the available values for this field. |
| byte 52 | Last Mode | This byte contains a value reflecting the previous mode that had control of the RC4000. See section A.3 of this document for more information about the available values for this field. |
| byte 53 | Exit Condition | This byte contains a value reflecting the reason the last mode was terminated and control switched to the current mode. See section A.3 of this document for more information about the available values for this field. |
| byte 54 | Extended Azimuth Position | For mounts with the ability to generate azimuth position to 0.01 degrees, this byte contains the digit for the one hundredth of a degree. This digit is to be added to the rest of the azimuth position contained in bytes 14-19. |
| byte 55 | Extended Elevation Position | For mounts with the ability to generate elevation position to 0.01 degrees, this byte contains the digit for the one hundredth of a degree. This digit is to be added to the rest of the elevation position contained in bytes 20-25. |
| bytes 56-58 | Reserved | |
| byte 59 | ETX | |
| byte 60 | Checksum | |

3.17 Remote Locate Command

This command requests the RC4000 to perform a LOCATE operation based on the satellite data supplied. The command is designed to allow an M&C system to simulate entering satellite data manually or selecting a satellite from the user's preset list stored in the RC4000.

NOTE: The M&C system is required to have confidence that the preset list is programmed correctly. The Write Satellite Data command (39h) and Read Satellite Data command (3Ah) may be used to gain confidence that the preset satellite list is correct.

The RC4000 will automatically sequence through the LOCATE operation. Any action that normally requires user action from the front panel will be automatically initiated.

The command contains 37 bytes with the following format:

| | | |
|--------|-----|--------------|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 41h | command code |

| | | | | | | | |
|--------|---------------------------------|--|--|--|--|--|--|
| byte 3 | Preset Flag & Preset Index Tens | | | | | | |
|--------|---------------------------------|--|--|--|--|--|--|

| | | | | | | | |
|---|---|---|---|----|---|---|---|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| 0 | 1 | 0 | A | \$ | 0 | 0 | B |

A – 1 = perform LOCATE to a preset satellite from the user list stored in the RC4000

NOTE: Bytes 5-28 should be set to blanks.

NOTE: This option is required to locate a satellite that has beacon or ephemeris data associated with it.

A – 0 = perform LOCATE to a satellite using name, longitude, inclination and band data supplied in bytes 5-28.

B – Tens digit of preset satellite index (0 if index < 10), or blank if not specifying a preset satellite.

| | | |
|--------|------------|---|
| byte 4 | Index Ones | Ones digit of preset satellite index, or blank if not specifying a preset satellite |
|--------|------------|---|

| | | |
|------------|----------|-----------------------------|
| bytes 5-14 | Sat Name | 10 character satellite name |
|------------|----------|-----------------------------|

| | | |
|-------------|-----------|--|
| bytes 15-20 | Longitude | Nominal satellite longitude -179.9 to 179.9 (West longitude negative) Left Justify and pad with blanks |
|-------------|-----------|--|

| | | |
|-------------|-------------|--|
| bytes 21-22 | Inclination | Satellite inclination 0 to 19 Left Justify and pad with blanks |
|-------------|-------------|--|

| | | |
|---------|------|--|
| byte 23 | Band | RF Band (0-C, 1-Ku, 2-C/Ku, 3-L, 4-X, 5-Ka, 6-S) |
|---------|------|--|

Remote Locate Command (continued)

| | | |
|-------------|--------------------|---|
| bytes 24-28 | Pol Offset | Satellite Polarization Offset (relative to equatorial plane) -90.0 to 90.0 (CCW negative) Left Justify and pad with blanks |
| byte 29 | Polarization | Receive Polarization Selection H – Horizontal V – Vertical N – Neutral X – None NOTE: Not applicable if feed type is circular. |
| byte 30 | Position Update | A – Automatically determine missing mount position data U – Force an update of all mount position data |
| byte 31 | Locate Source | |
| | 7 6 5 4 3 2 1 0 | |
| | 0 1 0 A \$ B B B B | |
| | | A – 0 = use locate source config value A – 1 = locate source specified in lower nibble |
| | | Where 'BBBB' is defined as: |
| | | 0000 – None |
| | | 0001 – Receiver 1 (or external beacon) |
| | | 0010 – Receiver 2 (or internal beacon) |
| | | 0101 – RF |
| | | 0110 – DVB (if available) |
| | | 0111 – Remote (if available) |
| bytes 32-34 | Reserved | fill with zeros or blanks |
| byte 35 | | ETX |
| byte 36 | | Checksum |

The reply to this command will be the standard ACK or NAK reply. ACK implies that LOCATE operation will be initiated. Progress of the LOCATE operation may be monitored via the Extended Device Status Poll command. NAK implies an error in the supplied satellite data

3.18 Remote Store Command

This command requests the RC4000 to perform a STORE operation based on the satellite data supplied.

The RC4000 will automatically sequence through the STORE operation. Any action that normally requires confirmation from the front panel will be automatically initiated. If a particular satellite name has already been STOREd, it's data will be overwritten as a result of the Remote Store command.

NOTE: It is assumed that the satellite has been positively identified and is currently peaked up in azimuth and elevation prior to performing a STORE operation. It is also assumed that Horizontal and Vertical polarization positions have been confirmed.

The command contains 48 bytes with the following format:

| | | |
|--------|-----|--------------|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 42h | command code |

byte 3 Preset Flag & Preset Index Tens

```

7 6 5 4   3 2 1 0
0 1 0 A $ 0 0 0 B

```

A – 1 = perform STORE of a satellite defined from the user preset list stored in the RC4000.

NOTE: This option is required to reference an inclined orbit satellite that has ephemeris data associated with it.

A – 0 = perform STORE of a satellite using name, longitude, inclination and band data supplied in bytes 5- 39.

B – Tens digit of preset satellite index
(0 if index < 10): index value may be between 1 to 20

| | | |
|-------------|-------------|---|
| byte 4 | Index Ones | Ones digit of preset satellite index |
| bytes 5-14 | Sat Name | 10 character satellite name |
| bytes 15-20 | Longitude | Nominal satellite longitude -179.9 to 179.9 (West longitude negative) Left Justify and pad with blanks |
| bytes 21-22 | Inclination | Satellite inclination 0 to 19 Left Justify and pad with blanks |
| byte 23 | Band | RF Band (0-C, 1-Ku, 2-C/Ku, 3-L, 4-X, 5-Ka, 6-S) |

Remote Store Command (continued)

| | | |
|-------------|----------------------------------|---|
| bytes 24-28 | Pol Offset | Satellite Polarization Offset -90.0 to 90.0 negative = counterclockwise Left Justify and pad with blanks |
| byte 29 | Polarization Selection | C – use calculated H,V values NOTE: Requires that a LOCATE function has been preformed immediately prior to the Remote Store. S – use H,V values supplied in bytes 30-39 H – use current pol as horizontal and calculate vertical V – use current pol as vertical and calculate horizontal |
| bytes 30-34 | Horizontal Polarization Position | -90.0 to 90.0 |
| bytes 35-39 | Vertical Polarization Position | -90.0 to 90.0 NOTE: Polarization Selection, Horizontal and Vertical Positions are not applicable if feed type is circular |
| byte 40 | Track Polarization | Selects which Polarization position to use when TRACK initiated (applicable to inclined orbit satellites only) H – Horizontal V – Vertical |
| bytes 41-45 | Reserved | fill with zeros or blanks |
| byte 46 | | ETX |
| byte 47 | | Checksum |

The reply to this command will be the standard ACK or NAK reply. ACK implies that STORE operation will be initiated. NAK implies an error in the supplied satellite data

3.19 Write Signpost Data Command

This command downloads signpost data into the RC4000 list of user defined signposts.

| | | |
|-------------|--------------|---|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 43h | command code |
| byte 3-4 | Index | Signpost data table index (01–10) |
| bytes 5-10 | Longitude | Nominal satellite longitude -179.9 to 180.0 (West longitude negative) Left Justify and pad with blanks |
| bytes 11-15 | Frequency | 10700 to 12750 Left Justify and pad with blanks |
| bytes 16-20 | Symbol Rate | 1000 to 40000 Left Justify and pad with blanks |
| byte 21 | FEC | Forward Error Correction Code type 1 – 9 1 = 1 / 2, 2 = 2 / 3, 3 = 3 / 4, 5 = 5 / 6, 6 = 6 / 7, 7 = 7 / 8, 9 = AUTO |
| byte 22 | Polarization | H = horizontal, V = vertical L = LHCP, R = RHCP |
| bytes 23-28 | Reserved | fill with zeros or blanks |
| byte 29 | Priority | 0 – 9 relative search priority |
| byte 30 | Standard | 1 = DVB-S1 2 = DVB-S2 |
| byte 31 | Modulation | 1 = QPSK 2 = 8PSK 3 = 16PSK |
| bytes 32-33 | Reserved | fill with zeros or blanks |
| byte 34 | ETX | |
| byte 35 | Checksum | |

The reply to this command will be the standard ACK or NAK reply.

Data written with this command must be saved to persist between power cycles. The Write Config Data Command should be executed after all changes have been made. Refer to section 3.25 of this document for more information.

3.20 Read Signpost Data Command

This command uploads a stored set of signpost data.

| | | |
|----------|----------|-----------------------------------|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 44h | command code |
| byte 3-4 | Index | Signpost data table index (01–10) |
| byte 5 | ETX | |
| byte 6 | Checksum | |

The reply to this command is as follows:

| | | |
|-------------|--------------|---|
| byte 0 | ACK or NAK | |
| byte 1 | A | address |
| byte 2 | 44h | command code |
| byte 3-4 | Index | Signpost data table index (01–10) |
| bytes 5-10 | Longitude | Nominal satellite longitude -179.9 to 180.0 (West longitude negative) Left Justify and pad with blanks |
| bytes 11-15 | Frequency | 10700 to 12750 Left Justify and pad with blanks |
| bytes 16-20 | Symbol Rate | 1000 to 40000 Left Justify and pad with blanks |
| byte 21 | FEC | Forward Error Correction Code type 1 – 9 1 = 1 / 2, 2 = 2 / 3, 3 = 3 / 4, 5 = 5 / 6, 6 = 6 / 7, 7 = 7 / 8, 9 = AUTO |
| byte 22 | Polarization | H = horizontal, V = vertical L = LHCP, R = RHCP |
| bytes 23-28 | Reserved | |
| byte 29 | Priority | 1 – 9 relative search priority |
| byte 30 | Standard | 1 = DVB-S1 2 = DVB-S2 |
| byte 31 | Modulation | 1 = QPSK 2 = 8PSK 3 = 16PSK |
| bytes 32-33 | Reserved | |
| byte 34 | ETX | |
| byte 35 | Checksum | |

3.21 Read Navigation Data Command

This command uploads the current values of navigation data.

| | | |
|--------|----------|--------------|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 45h | command code |
| byte 3 | ETX | |
| byte 4 | Checksum | |

The reply to this command is as follows:

| | | |
|--------|------------|--------------|
| byte 0 | ACK or NAK | |
| byte 1 | A | address |
| byte 2 | 45h | command code |

byte 3 Latitude/Longitude Source

```

7 6 5 4   3 2 1 0
0 1 0 0 $ 0 X X X

```

where 'XXX' is ...

- 001 – Lat/Lon data invalid
- 010 – Lat/Lon read from GPS
- 011 – User entered location
- 100 – User selected preset location
- 101 – Reserved
- 110 – Remotely entered lat/lon

bytes 4-8 Latitude +ddmm (+/- degrees, minutes format)
right justified, padded with blanks
-9000 to +9000 or blanks if not available
minus = South, positive (implied) = North
1234 = 12 degrees 34 minutes N
-1234 = 12 degrees 34 minutes S

bytes 9-12 Reserved

bytes 13-18 Longitude +dddmm (+/- degrees, minutes format)
right justified, padded with blanks
-18000 to +18000 or blanks if not available
minus = West, positive (implied) = East
1234 = 12 degrees 34 minutes E
-1234 = 12 degrees 34 minutes W

bytes 19-28 Reserved

Read Navigation Data Command (continued)

| | | |
|-------------|----------------------|---|
| byte 29 | True Heading Source | |
| | | <pre> 7 6 5 4 3 2 1 0 0 1 0 0 \$ 0 X X X </pre> |
| | where 'XXX' is ... | 001 – Heading data invalid 010 – Heading read from compass 011 – User entered magnetic heading 100 – User entered true heading 101 – Heading fixed by user 110 – Heading fixed automatically 111 – Remotely entered heading |
| bytes 30-34 | True Heading | ddd.d (decimal degrees format) 0.0 to 359.9 or blanks if not available True Heading of mount at azimuth 0.0 |
| byte 35 | Magvar Status | 0x41h if magvar ready (calculated) 0x40h if magvar not ready |
| bytes 36-41 | Magnetic Variation | +dd.d (decimal degrees format) right justified, padded with blanks -99.9 to 99.9 or blanks if magvar not available (westerly variation negative) |
| byte 42-58 | Reserved | |
| byte 59 | Platform Tilt Source | |
| | | <pre> 7 6 5 4 3 2 1 0 0 1 0 0 \$ 0 X X X </pre> |
| | where 'XXX' is ... | 001 – Currently no tilt data 010 – Automatically determined tilt data 011 – Remotely entered tilt data |
| bytes 60-64 | Platform Pitch | +dd.d (decimal degrees format) right justified, padded with blanks -99.9 to 99.9 or blanks if not available |
| bytes 65-69 | Platform Roll | +dd.d (decimal degrees format) right justified, padded with blanks -99.9 to 99.9 or blanks if not available |
| byte 70 | ETX | |
| byte 71 | Checksum | |

3.22 Write Navigation Data Command

This command downloads antenna position data into the RC4000.

| | | |
|-------------|--------------------|--|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 46h | command code |
| bytes 3-7 | Latitude | +ddmm (+/- degrees, minutes format) right justified, padded with blanks -9000 to 9000 minus = South, positive (implied) = North 1234 = 12 degrees 34 minutes N -1234 = 12 degrees 34 minutes S |
| bytes 8-13 | Longitude | +dddmm (+/- degrees, minutes format) right justified, padded with blanks -18000 to 18000 minus = West, positive (implied) = East 1234 = 12 degrees 34 minutes E -1234 = 12 degrees 34 minutes W |
| bytes 14-18 | True Heading | ddd.d (decimal degrees format) right justified, padded with blanks 0.0 to 359.9 True Heading of mount at azimuth 0.0 12.3 = 12.3 degrees 179.4 = 179.4 degrees |
| byte 19 | Update Lat/Lon | 'A' – do not change lat/lon values 'U' – force update using GPS 'M' – use manual data from fields above |
| byte 20 | Update Heading | 'A' – do not change compass value 'U' – force update using compass 'M' – use manual data from fields above |
| byte 21 | Update Options | |
| | 7 6 5 4 3 2 1 0 | |
| | 0 1 0 A \$ 0 0 0 0 | |
| | where 'A' is ... | 0 – Update source flags only. 1 – Execute update sequence (REMOTE_NAV mode). (will move antenna to deploy) |
| bytes 22-26 | Reserved | fill with zeroes or blanks |

Write Navigation Data Command (continued)

| | | |
|-------------|----------------|--|
| bytes 27-31 | Platform Pitch | +dd.d (+/- degrees format) right justified, padded with blanks -90.0 to 90.0 12.3 = 12.3 degrees -11.4 = -11.4 degrees |
| bytes 32-36 | Platform Roll | +dd.d (+/- degrees format) right justified, padded with blanks -90.0 to 90.0 12.3 = 12.3 degrees -11.4 = -11.4 degrees |
| bytes 37 | Update Tilt | 'A' – do not change pitch/roll values 'U' – force update of tilt 'M' – use manual data from fields above |
| bytes 38-40 | Reserved | spare for future expansion (fill with blanks) |
| byte 41 | ETX | |
| byte 42 | Checksum | |

The reply to this command will be the standard ACK or NAK reply.

3.23 Azimuth/Elevation/Polarization Jog Command (with minimal reply)

This command jogs the antenna in azimuth, elevation or polarization. It is functionally the same command as described in section 3.4 but with a much shorter reply. Rather than sending the full status reply, only the position (at the time the command is received) of the selected axis is returned.

The reply to this query will consist of 12 bytes:

| | | |
|-----------|---------------|---|
| byte 0 | ACK | |
| byte 1 | A | address |
| byte 2 | 47h | command code |
| byte 3 | "A/E/P" | Axis jogged: A(zimuth), E(levation) or P(olarization) |
| bytes 4-9 | Axis Position | This field will contain the formatted axis position in the range -180.0 to 180.0. If the analog to digital converter detects an error this field will contain '*****'. |
| byte 10 | ETX | |
| byte 11 | Checksum | |

3.24 Remote Key Press Command

This command sends a keypad value to the RC4000. The RC4000 will react to the keypad value as if the corresponding key on the RC4000 front panel was pushed.

The format of the command is as follows:

| | | |
|--------|----------|----------------------------|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 48h | command code |
| byte 3 | Key Code | key codes as defined below |
| byte 4 | ETX | |
| byte 5 | Checksum | |

| CODE | KEY |
|--------|-------------------|
| 30h | 0/Speed |
| 31h | 1/PoI CCW |
| 32h | 2/N/EL UP |
| 33h | 3/PoI CW |
| 34h | 4/E/AZ CCW |
| 35h | 5 |
| 36h | 6/W/AZ CW |
| 37h | 7/H |
| 38h | 8/S/EL DN |
| 39h | 9/V |
| 3A-3Fh | -- unused -- |
| 41h | Stop/decimal pt. |
| 42h | +/-/BKSP |
| 43h | Mode |
| 44h | Scroll Up/Yes |
| 45h | Scroll Dn/No |
| 46h | Enter |
| 47h | Mode Group Change |
| 48h | Null Key |

NOTE: The 47h key code can be used to initiate a RC4000 mode group change which normally requires the Mode key to be held down for five seconds continuously.

The reply to this command will be the standard ACK or NAK reply.

3.25 Write Config Data Command

This command writes CONFIG item values to the RC4000 memory. Data values written by some remote commands are not committed to the flash memory until the save command is sent.

Flash memory has a limited number of write times. Care should be taken to avoid unnecessary calling of this command. For example, if changing a number of preset satellites, don't call Write Config Data until all Write Satellite Commands have been sent and acknowledged.

The save command should be in the following format:

| | | |
|-----------|----------|---|
| byte 0 | STX | |
| byte 1 | A | address |
| byte 2 | 49h | command code |
| byte 3-15 | "SAVE" | The save command should be left-justified and padded with blanks. |
| byte 16 | ETX | |
| byte 17 | Checksum | |

The reply to this command will be the standard ACK or NAK reply.

NOTE: The ACU current mode will change to FLASH_SAVE_MODE temporarily while flash data is saved.

3.26 Custom Device Status Command

This command requests status information given a variable list of Object IDs. A full list of available OIDs is given in section A.4 of this document.

| | | |
|----------|------------|---|
| byte 0 | | STX |
| byte 1 | A | address |
| byte 2 | 4Bh | command code |
| byte 3-n | Object IDs | A comma-delimited list of up to 16 OIDs. Each code should be in ASCII format with no padding. Example: 1.62.0,1.62.1 requests the azimuth and elevation angles |
| byte n+1 | ETX | |
| byte n+2 | Checksum | |

The response to this command will be a comma-delimited list of the requested OIDs and related status values in the same order as they were requested. The return values will be the ASCII representation of character, numeric, or hexadecimal data. The return type is given in section A.4 of this document.

The reply will be in the following format:

| | | |
|----------|---------------|---|
| byte 0 | ACK | |
| byte 1 | A | address |
| byte 2 | 4Bh | command code |
| byte 3-n | Object Values | A comma-delimited list of status object values. Each value will be in ASCII format with no padding. No data will be returned if a requested object ID is invalid. Example: 1.62.0=-22.3,1.62.0=47.1 is the reply containing the current azimuth angle (-22.3) and elevation angle (47.1) |
| byte n+1 | ETX | |
| byte n+2 | Checksum | |

NOTE: This functionality is experimental and may change without notice.

4.0 TROUBLESHOOTING

No Communication between RC4000 and the remote control computer.

There are numerous situations that could cause no communication:

- 1) The address set in the RC4000 is not being used by the remote commands. Check the address in the REMOTE configuration screen and ensure that address is being sent with the commands. Incorrectly addressed commands will be ignored by the RC4000.
- 2) The baud rate set in the RC4000 is not being used by the remote commands. Check the baud rate in the REMOTE configuration screen and ensure that it is the same as being used by the remote computer. Commands sent at the incorrect baud rate will not be recognized by the RC4000.
- 3) The remote computer or RC4000 are not both set to RS-232 or RS-422/RS-485. The remote control system should determine whether it is to work in RS-232, -422 or -485 mode. Check the configuration of the remote jumper and the placement of the cable inside of the RC4000, as described in 2.2.11. Also check the cabling between the RC4000 and the remote computer.
- 4) The RS-422 adapter is not compatible with the RC4000. Occasionally it has been found that a commercially available RS-422 adapter will just not work with the RC4000. To check for this possibility, temporarily mechanize the interface via RS-232 and see if communications is established.
- 5) The remote computer is not actually transmitting through the intended communication port. To check for this possibility, mechanize a "loop back" right at the communication port of the remote computer. The receive mode of the remote control software should see an exact reflection of the transmitted command.

Unreliable Communications or ACU Reset.

There are some situations that may cause the remote control communications to be unreliable (such as a garbled status reply) or in the extreme situation to cause the ACU to reset.

- 1) Allow a previous command to ACK or NAK before sending another command.
- 2) Don't repeatedly ask for "static" information such as navigation or satellite data.
- 3) The general recommendation is not to send commands (particularly status requests) at a rate greater than once a second.

5.0 REFERENCE INFORMATION

5.1 MESSAGE DELIMITERS

Here are the delimiters used with SA bus messages, along with their values in hex and decimal.

| ASCII name | hex value | decimal value |
|------------|-----------|---------------|
| STX | 2 | 2 |
| ETX | 3 | 3 |
| ACK | 6 | 6 |
| NAK | 15 | 21 |

5.2 ASCII TABLE

As reference, the following table shows the set of ASCII codes available for use by the RC4000 remote protocol.

| HEX | 0_ | 1_ | 2_ | 3_ | 4_ | 5_ | 6_ | 7_ |
|-----|------------|------------|--------------|-------------|----------|----------|----------|----------|
| _0 | | | Blank | 0 | @ | P | | p |
| _1 | | | ! | 1 | A | Q | a | q |
| _2 | STX | | " | 2 | B | R | b | r |
| _3 | ETX | | # | 3 | C | S | c | s |
| _4 | | | \$ | 4 | D | T | d | t |
| _5 | | NAK | % | 5 | E | U | e | u |
| _6 | ACK | | & | 6 | F | V | f | v |
| _7 | | | ' | 7 | G | W | g | w |
| _8 | | | (| 8 | H | X | h | x |
| _9 | | |) | 9 | I | Y | i | y |
| _A | | | * | : | J | Z | j | Z |
| _B | | | + | ; | K | [| k | { |
| _C | | | , | < | L | \ | l | |
| _D | | | - | = | M |] | m | } |
| _E | | | . | > | N | ^ | n | |
| _F | | | / | ? | O | _ | o | |

5.3 EXTENDEND STATUS REPLY TABLES

The following tables define the possible values for bytes 45-48 of the Extended Device Status Poll reply. Possible values are listed for the RC4000 operating modes, exit conditions, and current state per mode.

| Value (hex) | Value (dec) | Mode (bytes 45 & 47) | MANUAL States | DEPLOY States | STOW States |
|-------------|-------------|----------------------|-------------------|----------------------------|---------------------------|
| 20 | 32 | MANUAL | INITIALIZING_MODE | INITIAIZING_MODE | INITIALIZING_MODE |
| 21 | 33 | MENU | JOG_AZIM_CCW | | |
| 22 | 34 | POSITION | JOG_AZIM_CW | MOVING_ELEV | STARTING_OPERATION |
| 23 | 35 | | JOG_ELEV_DOWN | MOVING_AZIM | MOVING_OUT_OF_DOWN |
| 24 | 36 | | JOG_ELEV_UP | MOVING_AZELPL | MOVING_TO_AZPL_POSITION |
| 25 | 37 | LOCATE | JOG_POL_CW | MOVING_SPECIAL_AXIS | |
| 26 | 38 | | JOG_POL_CCW | SPECIAL_AXIS_NOT_AT_DEPLOY | SEARCHING_FOR_AZIM_SWITCH |
| 27 | 39 | STORE | AUTO_POL_MOVE | | CANNOT_FIND_AZ_SWITCH |
| 28 | 40 | TRACK | IDLE | | |
| 29 | 41 | | | | SEARCHING_FOR_POL_SWITCH |
| 2A | 42 | SPECIAL_AXIS | | | CANNOT_FIND_POL_SWITCH |
| 2B | 43 | POS_CONFIRM | | | |
| 2C | 44 | | | | MOVING_TO_ELEV_STOW |
| 2D | 45 | HEADING_FIX | | | MOVING_SPECIAL_AXIS |
| 2E | 46 | | | | ELEV_NOT_AT_STOW |
| 2F | 47 | STOW | | | SPECIAL_AXIS_NOT_AT_STOW |
| 30 | 48 | DEPLOY | | | COMPLETE |
| 31 | 49 | RECALL | | | |
| 32 | 50 | AUTO_MOVE | | | |
| 33 | 51 | | | | |
| 34 | 52 | | | | |
| 35 | 53 | | | | |
| 36 | 54 | RESET_DRIVE | | | |
| 37 | 55 | DELETE | | | |
| 38 | 56 | FLASH_SAVE | | | |
| 39 | 57 | | | | |
| 3A | 58 | | | | |
| 3B | 59 | | | | |
| 3C | 60 | | | | |
| 3D | 61 | | | | |
| 3E | 62 | | | | |
| 3F | 63 | | | | |
| 40 | 64 | | | | |

| Value (hex) | Value (dec) | LOCATE States | TRACK States |
|-------------|-------------|------------------------------------|-----------------------------------|
| 20 | 32 | ENTERING_MODE | ENTERING_MODE |
| 21 | 33 | | |
| 22 | 34 | DEPLOYING_ANTENNA | INITIALIZING_DISPLAY |
| 23 | 35 | | DEPLOYING_ELEV_AXIS |
| 24 | 36 | | POSITIONING_POLARIZATION |
| 25 | 37 | | WAITING_FOR_EXIT_CONFIRMATION |
| 26 | 38 | | INITIALIZING_PARAMETERS |
| 27 | 39 | | STEP_PEAKING |
| 28 | 40 | | STEP_WAITING_FOR_SIGNAL_TO_RETURN |
| 29 | 41 | | STEP_IDLE |
| 2A | 42 | WAITING_FOR_LAT_LON | SEARCH_PERFORMING_SEARCH_PATTERN |
| 2B | 43 | WAITING_FOR_HEADING | SEARCH_MOVING_TO_FOUND_PEAK |
| 2C | 44 | | SEARCH_WAITING_TO_SEARCH_AGAIN |
| 2D | 45 | | MANUAL_SEARCH_NOMINAL_AZEL_MOVE |
| 2E | 46 | READY_TO_LOCATE | MANUAL_SEARCH_NOMINAL_ELEV_MOVE |
| 2F | 47 | AZIMUTH_RANGE_ERROR | MANUAL_SEARCH_NOMINAL_AZIM_MOVE |
| 30 | 48 | ELEVATION_RANGE_ERROR | MANUAL_SEARCH_ACTIVE |
| 31 | 49 | | MEMORY_IDLE |
| 32 | 50 | | MEMORY_PEAKING |
| 33 | 51 | | MEMORY_REPOSITION |
| 34 | 52 | | ERROR_CREEP_JAMMED |
| 35 | 53 | | ERROR_CREEP_LIMIT |
| 36 | 54 | DETERMINING_TILT | ERROR_CREEP_DRIVE |
| 37 | 55 | | ERROR_PEAK_LIMIT |
| 38 | 56 | | ERROR_SCALE_FACTOR |
| 39 | 57 | | ERROR_GEO |
| 3A | 58 | | ERROR_SYSTEM |
| 3B | 59 | | ERROR_CHECKSUM |
| 3C | 60 | | ERROR_UNDEFINED_STATUS |
| 3D | 61 | | MENU_WAITING_FOR_SELECTION |
| 3E | 62 | CALCULATING_TLE | MENU_VIEW |
| 3F | 63 | | MENU_MODIFY |
| 40 | 64 | FIRST_MOVEMENT | TLE_IDLE |
| 41 | 65 | AZIM_MOVEMENT | TLE_REPOSITION |
| 42 | 66 | ELEV_MOVEMENT | MANUAL_SEARCH_JOG_AZIM_CCW |
| 43 | 67 | POL_MOVEMENT | MANUAL_SEARCH_JOG_AZIM_CW |
| 44 | 68 | SAMPLE_AGC_DURING_SCAN_STEP | MANUAL_SEARCH_JOG_ELEV_DOWN |
| 45 | 69 | MOVING_TO_INITIAL_SCAN_POSITION | MANUAL_SEARCH_JOG_ELEV_UP |
| 46 | 70 | | MANUAL_SEARCH_JOG_POL_CW |
| 47 | 71 | AZIMUTH_SMOOTH_SCAN | MANUAL_SEARCH_JOG_POL_CCW |
| 48 | 72 | | MANUAL_SEARCH_AUTO_POL_MOVE |
| 49 | 73 | AZIMUTH_STEP_SCAN | MANUAL_SEARCH_IDLE |
| 4A | 74 | MOVING_TO_LOCK_CENTER | |
| 4B | 75 | MOVING_TO_SCAN_PEAK | |
| 4C | 76 | MOVING_TO_NOMINAL_AZEL | |
| 4D | 77 | | |
| 4E | 78 | SCAN_NO_PEAK_FOUND | |
| 4F | 79 | BEGINNING_SPIRAL_SEARCH | |
| 50 | 80 | SPIRAL_MOVING_TO_STARTING_POSITION | |
| 51 | 81 | SPIRAL_SEARCH_STEPPING_CW | |
| 52 | 82 | | |
| 53 | 83 | | |
| 54 | 84 | | |
| 55 | 85 | SPIRAL_SEARCH_STEPPING_UP | |
| 56 | 86 | | |
| 57 | 87 | SPIRAL_SEARCH_STEPPING_CCW | |
| 58 | 88 | | |
| 59 | 89 | | |
| 5A | 90 | | |
| 5B | 91 | SPIRAL_SEARCH_STEPPING_DOWN | |
| 5C | 92 | SPIRAL_PEAK_MOVING_TO_PEAK_AZEL | |
| 5D | 93 | SPIRAL_MOVING_TO_NOMINAL_AZEL | |
| 5E | 94 | | |
| 5F | 95 | SPIRAL_NO_PEAK_FOUND | |

| | | | |
|----|-----|-------------------------|--|
| 60 | 96 | NO_LAT_LON | |
| 61 | 97 | NO_HEADING | |
| 62 | 98 | FEED_BAND_MISMATCH | |
| 63 | 99 | NO_SAT_DATA | |
| 64 | 100 | PARAMETER_ERROR | |
| 65 | 101 | DETERMINE_NOISE_FLOOR | |
| 66 | 102 | INITIALIZE_DVB | |
| 67 | 103 | PERFORMING_PEAKUP | |
| 68 | 104 | COMPLETE | |
| 69 | 105 | TUNE_BEACON | |
| 6A | 106 | PERFORMING_POL_PEAKUP | |
| 6B | 107 | ADJUST_POL_FOR_TILT | |
| 6C | 108 | NO_RF_DETECTED | |
| 6D | 109 | DVB_INIT_FAILURE | |
| 6E | 110 | MOVING_TO_SIGNPOST_ELEV | |
| 6F | 111 | NO_SIGNPOST_FOUND | |
| 70 | 112 | | |

| Value (hex) | Value (dec) | STORE States | RECALL States | SPECIAL_AXIS States |
|-------------|-------------|-----------------------|---------------------------|---------------------|
| 20 | 32 | ENTERING_MODE | ENTERING_MODE | ELEV_BELOW_DOWN |
| 21 | 33 | ERROR_NO_LAT_LON | NO_SATS_STORED | |
| 22 | 34 | ERROR_NO_SAT_SELECTED | | |
| 23 | 35 | ERROR_SATDATA_FULL | | |
| 24 | 36 | SAVING_SATDATA | | |
| 25 | 37 | MOVING_POL_FOR_TRACK | MOVING_ELEV_INTO_POSITION | |
| 26 | 38 | | MOVING_POL_INTO_POSITION | OPENING |
| 27 | 39 | | MOVING_AZIM_INTO_POSITION | CLOSING |
| 28 | 40 | | MOVING_AZEL_INTO_POSITION | |

5.4 STATUS OBJECT IDS AND RETURN VALUE TYPES

NOTE: This functionality is experimental and may change at any time without notice.

The following table defines the available status OIDs and their return value types. All values are returned as ASCII characters formatted in the manner described. Supplemental tables follow with individual item detail where indicated.

Table 5.4.1 – Object IDs

| OID | Status Item | Format | Description |
|--------|--------------------------------|--------------|------------------------------|
| 1.0.0 | MODE_ITEM | Unsigned | See Section 5.3 |
| 1.1.0 | SUBMODE_ITEM | Unsigned | See Section 5.3 |
| 1.2.0 | LAST_MODE_ITEM | Unsigned | See Section 5.3 |
| 1.3.0 | LAST_SUBMODE_ITEM | Unsigned | See Section 5.3 |
| 1.4.0 | DATE_ITEM (future) | ASCII String | YYYY-MM-DD (10 Characters) |
| 1.5.0 | TIME_ITEM (future) | ASCII String | HH:MM:SS (8 Characters) |
| 1.6.0 | ACTIVE_ALARM_ITEM | Enumeration | Table 5.4.2 |
| 1.10.0 | LOCAL_JOG_CONNECTED_ITEM | Unsigned | 0=Not Connected, 1=Connected |
| 1.13.0 | POS_SAVED_ITEM | Unsigned | 0 = Not Saved, 1=Saved |
| 1.14.0 | POS_LOC_SOURCE_ITEM | Enumeration | Table 5.4.3 – Location |
| 1.15.0 | POS_LOC_LAT_ITEM | Signed | +DDMM (degrees/minutes) |
| 1.16.0 | POS_LOC_LON_ITEM | Signed | +DDDMM (degrees/minutes) |
| 1.17.0 | POS_LOC_ALT_ITEM | Unsigned | AAAA (meters) |
| 1.18.0 | POS_HDG_SOURCE_ITEM | Enumeration | Table 5.4.3 – Heading |
| 1.19.0 | POS_HDG_ITEM | Float | +DDD.DD (degrees) |
| 1.20.0 | POS_TILT_SOURCE_ITEM | Enumeration | Table 5.4.3 – Tilt |
| 1.21.0 | POS_TILT_PITCH_ITEM | Signed | +DD.D (degrees) |
| 1.22.0 | POS_TILT_ROLL_ITEM | Signed | +DD.D (degrees) |
| 1.29.0 | SAT_SOURCE_ITEM | Enumeration | Table 5.4.3 – Satellite |
| 1.30.0 | SAT_POLARIZATION_ITEM | Enumeration | Table 5.4.3 – Polarization |
| 1.31.0 | SAT_PRESET_NUM_ITEM | Unsigned | 0 – 19 |
| 1.32.0 | SAT_NAME_ITEM | ASCII String | 10 Characters |
| 1.33.0 | SAT_LON_ITEM | Float | +DDD.D (degrees) |
| 1.34.0 | SAT_INCLIN_ITEM | Signed | +DD (degrees) |
| 1.35.0 | SAT_BAND_ITEM | Enumeration | Table 5.4.3 – Band |
| 1.36.0 | SAT_POL_OFFSET_ITEM | Float | +DD.D (degrees) |
| 1.37.0 | SAT_EPHEM_ITEM | Unsigned | 0=None, 1=TLE |
| 1.38.0 | SAT_BEACON_FREQ_ITEM (future) | Unsigned | DDDDDDDD (kHz) |
| 1.39.0 | SAT_BEACON_ATTEN_ITEM (future) | Unsigned | DD (dB) |
| 1.40.0 | SAT_BEACON_DEMOD_ITEM | Unsigned | 0=CW, 1=BPSK |
| 1.49.0 | TARGET_AZ_ITEM | Float | +DDD.D (degrees) |
| 1.50.0 | TARGET_EL_ITEM | Float | +DDD.D (degrees) |
| 1.51.0 | TARGET_PL_H_ITEM | Float | +DDD.D (degrees) |
| 1.52.0 | TARGET_PL_V_ITEM | Float | +DDD.D (degrees) |
| 1.53.0 | TARGET_RANGE_ITEM | Unsigned | +DDDDD (miles) |

| OID | Status Item | Format | Description |
|------------|-------------------------|---------------|----------------------------------|
| 1.62.0 | AXIS_ANGLE_ITEM: AZ | Float | +DDD.D (degrees) |
| 1.62.1 | AXIS_ANGLE_ITEM: EL | Float | +DDD.D (degrees) |
| 1.62.2 | AXIS_ANGLE_ITEM: PL | Float | +DDD.D (degrees) |
| 1.63.0 | AXIS_COUNT_ITEM: AZ | Unsigned | 0 – 65535 |
| 1.63.1 | AXIS_COUNT_ITEM: EL | Unsigned | 0 – 65535 |
| 1.63.2 | AXIS_COUNT_ITEM: PL | Unsigned | 0 – 65535 |
| 1.64.0 | AXIS_LIMITS_ITEM: AZ | Hexadecimal | Table 5.4.4 |
| 1.64.1 | AXIS_LIMITS_ITEM: EL | Hexadecimal | Table 5.4.4 |
| 1.64.2 | AXIS_LIMITS_ITEM: PL | Hexadecimal | Table 5.4.4 |
| 1.65.0 | AXIS_ALARMS_ITEM: AZ | Hexadecimal | Table 5.4.5 |
| 1.65.1 | AXIS_ALARMS_ITEM: EL | Hexadecimal | Table 5.4.5 |
| 1.65.2 | AXIS_ALARMS_ITEM: PL | Hexadecimal | Table 5.4.5 |
| 1.75.0 | TRACK_STATUS_ITEM | Unsigned | Table 5.4.6 – Status |
| 1.76.0 | TRACK_ERROR_ITEM | Unsigned | Table 5.4.6 – Error |
| 1.77.0 | TRACK_BAND_ITEM | Enumeration | Table 5.4.3 – Band |
| 1.86.0 | SIGNAL_SOURCE_ITEM | Enumeration | Table 5.4.3 – Signal |
| 1.87.0 | SIGNAL_LEVEL_ITEM | Unsigned | 0 – 4095 |
| 1.88.0 | SIGNAL_LOCK_ITEM | Unsigned | 0=Off, 1=On, 2=None Defined |
| 1.93.0 | HPA_ENABLE_ITEM | Unsigned | 0=Disabled, 1=Tx Mute, 2=Enabled |
| 1.94.0 | FEED_INDEX_ITEM | Unsigned | 0 – 7 |
| 1.95.0 | AUTO_LOCATE_ACTIVE_ITEM | Unsigned | 1=Active |

The following table lists possible values and description for the ACTIVE_ALARM_ITEM. Only the values that appear below are possible.

Table 5.4.2 – Alarm Values and Descriptions

| Value (dec) | Value (hex) | Description |
|-------------|-------------|-------------------------------|
| 0 | 00 | NO_ALARM_CODE |
| 1 | 01 | FLASH_VERSION_MISMATCH_CODE |
| 2 | 02 | FLASH_DATA_CORRUPT_CODE |
| 3 | 03 | NVRAM_VERSION_MISMATCH_CODE |
| 4 | 04 | NVRAM_DATA_CORRUPT_CODE |
| 5 | 05 | LOW_BATTERY_ALARM_CODE |
| 6 | 06 | TIME_DATE_ALARM_CODE |
| 7 | 07 | AZIM_JAM_ALARM_CODE |
| 8 | 08 | AZIM_RUNAWAY_ALARM_CODE |
| 9 | 09 | ELEV_JAM_ALARM_CODE |
| 10 | 0A | ELEV_RUNAWAY_ALARM_CODE |
| 11 | 0B | POL_JAM_ALARM_CODE |
| 12 | 0C | POL_RUNAWAY_ALARM_CODE |
| 13 | 0D | LIMITS_INACTIVE_ALARM_CODE |
| 14 | 0E | DRIVE_ERROR_ALARM_CODE |
| 15 | 0F | EMERGENCY_STOP_ALARM_CODE |
| 16 | 10 | HANDCRANK_MISSING_ALARM_CODE |
| 17 | 11 | MOVEMENT_INTERLOCK_ALARM_CODE |

The following table lists possible values for the following items: POS_LOC_SOURCE_ITEM, POS_HDG_SOURCE_ITEM, POS_TILT_SOURCE_ITEM, SAT_SOURCE_ITEM, SAT_POLARIZATION_ITEM, SAT_BAND_ITEM, TRACK_BAND_ITEM, and SIGNAL_SOURCE_ITEM. Only the values that are filled in below are possible.

Table 5.4.3 – Multiple Item Values and Descriptions

| Value (dec) | Location Source | Heading Source | Tilt Source | Satellite Source | Polarization | Band | Signal Source |
|-------------|-----------------|-----------------|-------------|------------------|--------------|------|-----------------------|
| 0 | None | None | None | None | None | C | None |
| 1 | GPS | Compass | Auto | Manual | Horizontal | Ku | Receiver 1 (External) |
| 2 | Manual | Manual Magnetic | Remote | Preset | Vertical | C/Ku | Receiver 2 (Internal) |
| 3 | Preset | Manual True | | Longitude/Band | Right-Hand | L | Reserved |
| 4 | Reserved | Heading Fixed | | | Left-Hand | X | Reserved |
| 5 | Remote | Auto Fixed | | | Neutral | Ka | L-Band Power |
| 6 | | Remote | | | | S | DVB |
| 7 | | | | | | | Remote |

The following table lists possible values for the AXIS_LIMITS_ITEM. The hexadecimal value represents a 3-byte bitmask containing limit information. An 'xx' indicates a "don't care". Any combination from 000000 to 030303 is possible.

Table 5.4.4 – Axis Limit Mask

| Value (hex) | MAX Limit | MIN Limit | STOW Limit |
|-------------|-----------|-----------|------------|
| 000000 | None | None | None |
| 01xxxx | Hard | | |
| 02xxxx | Soft | | |
| 03xxxx | Both | | |
| xx01xx | | Hard | |
| xx02xx | | Soft | |
| xx03xx | | Both | |
| xxxx01 | | | Hard |
| xxxx02 | | | Soft |
| xxxx03 | | | Both |

The following table lists possible values for the AXIS_ALARMS_ITEM mask. The hexadecimal value represents a 1-byte bitmask containing axis alarm information. Only the values listed below are possible.

Table 5.4.5 – Axis Alarm Mask

| Value (hex) | JAMMED | RUNAWAY | DRIVE | HALT |
|-------------|--------|---------|-------|------|
| 00 | | | | |
| 01 | Yes | | | |
| 02 | | Yes | | |
| 03 | Yes | Yes | | |
| 04 | | | Yes | |
| 05 | Yes | | Yes | |
| 06 | | Yes | Yes | |
| 07 | Yes | Yes | Yes | |
| 08 | | | | Yes |
| 09 | Yes | | | Yes |
| 0A | | Yes | | Yes |
| 0B | Yes | Yes | | Yes |
| 0C | | | Yes | Yes |
| 0D | Yes | | Yes | Yes |
| 0E | | Yes | Yes | Yes |
| 0F | Yes | Yes | Yes | Yes |

The following table lists possible values for TRACK_STATUS_ITEM and TRACK_ERROR_ITEM. Only the values that are filled in below are possible.

Table 5.4.6 – Track Status and Track Error Descriptions

| Value (dec) | Status Description | Error Description |
|--------------------|-------------------------------|--------------------------|
| 0 | Track Setup Sub-Mode Active | |
| 1 | Track Auto Mode Entry | |
| 2 | Step Track Sub-Mode Active | |
| 3 | Auto Search Sub-Mode Active | |
| 4 | Memory Track Sub-Mode Active | |
| 5 | Track Error Sub-Mode Active | |
| 6 | NORAD Track Sub-Mode Active | |
| 7 | Manual Search Sub-Mode Active | |
| 33 | | Move Jammed Error |
| 34 | | Move Limit Error |
| 35 | | Move Drive Error |
| 36 | | Peak Limit Error |
| 37 | | Azim Scale Factor Error |
| 38 | | Track Geo Error |
| 39 | | Track System Error |
| 40 | | Track Checksum Error |

//