

## Resetting The Rabbit

Shorting J5 pin 4 to J5 pin 9 for 7 seconds will restore the RC3K rabbit to the default TCP/IP settings as shown below:

DHCP: Off  
IP: 192.168.1.1  
Netmask: 255.255.255.0  
Gateway: 192.168.1.254  
DHCP DNS: Off  
DNS 1: 0.0.0.0  
DNS 2: 0.0.0.0

